



The Electro Magnetic uncoupler is designed to be fitted under the baseboard of a layout and can uncouple many types of couplings. When a current is passed through it, a magnetic field is formed which lifts the couplings. Some couplings will require an EM/2 adaptor to be fitted.

Gaugemaster Controls Plc.
 Ford Road, Arundel, West sussex. BN18 0BN.
 Tel: 01903 884321. Fax: 01903 884377.

Suitable for all coupling systems that use an Electromagnet. I.E. Seep 'N' gauge adaptors (EM/2), sprat & winkle, B&B, D&G, etc.

This unit does not require a CDU.

